Accessories for TD/TS series up to 800A

Susol

Electrical auxiliaries

Auxiliary switch (AX), Alarm switch (AL) and Fault alarm switch (FAL)

Auxiliary switch (AX)

Auxiliary switch is for applications requiring remote "ON" and "OFF" indication.

Each switch contains two contacts having a common connection.

One is open and the other closed when the circuit breaker is open, and vice-versa.



Alarm switch (AL)

Alarm switches offer provisions for immediate audio or visual indication of a tripped breaker due to overload, short circuit, shunt trip, or undervoltage release conditions.

They are particularly useful in automated plants where operators must be signaled about changes in the electrical distribution system. This switch features a closed contact when the circuit breaker is tripped automatically. In other words, this switch does not function when the breaker is operated manually.

Its contact is open when the circuit breaker is reset.



Fault alarm switch (FAL)

FAL Indicates that the breaker has tripped due to overload or short circuit. And, it can be applied to only circuit breakers with electronic trip units.

Contact operation

| 08080 | } |
|-------|-------|
| | , , , |
| | |
| | 4 |

| MCCB | ON | ON OFF | |
|---------------------------|---------------------------|------------------|---------------------------|
| Position of AX | AXc1 — O— AXa1 O— AXb1 | AXc1 —O | O— AXa1 O— AXb1 |
| Position of AL, FAL | ALc1 — O | - ALa1 - ALb1 | ALc1 — O— ALa1 O— ALb1 |

Technical data

| Conventional thermal current Ith | 5A | | | | TC | |
|-----------------------------------|-------------|------------|--------------|-------------|----------------|--|
| Rated operational current le | Current, le | | Minimum load | TD | | |
| with rated operational voltage Ue | Voltage | Resistance | Inductance | current | TS | |
| - Altemating current 50/60Hz AC | 125V | 5 | 3 | | | |
| | 250V | 3 | 2 | | TS160 TS250 | |
| | 500V | - | - | 5V DC 160mA | TS | |
| - Direct current DC | 30V | 4 | 3 | 30V DC 30mA | | |
| | 125V | 0.4 | 0.4 | | TS | |
| | 250V | 0.2 | 0.2 | | TS | |

Accessories for TD/TS series up to 800A

Susol

Electrical auxiliaries

Possible configuration of electrical auxiliaries

Maximum possibilities

| Phase | Accessory | TD160 | TS250 | TS630 | TS800 |
|-----------|------------|-------|-------|-------|-------|
| R (Left) | AX | - | 1 | 3 | 3 |
| | AL | 1 | 1 | - | - |
| | SHT or UVT | 1 | 1 | 1 | 1 |
| T (Right) | AX | 2 | 1 | - | - |
| | AL | - | - | 1 | 2 |
| | FAL | - | 1 | 1 | 1 |

Note) FAL can be applied to only MCCB with electronic trip release.

